

The image features a light gray background with two large, overlapping circles. The left circle is a solid light gray and contains the word "moshi" in a lowercase, sans-serif font. The right circle is white with a thin gray border and contains the title and date. The circles overlap in the center, creating a subtle shadow effect.

moshi

USB-C Digital Audio Adapter
Firmware update Instructions


11.06
/ 2019

Firmware Update Instructions

Preparations:


1. A computer with USB Type-C port(Running Windows 7 or later)
2. Moshi USB-C Digital Audio Adapter
3. A wired earphone
4. Download the” USB-C Digital Audio Adapter - FW updater”

Step 1



1. Connect your USB-C Digital Audio Adapter to the computer.
2. Connect the wired earphone to USB-C Digital Audio Adapter.

Step 2



1. Download the latest Firmware update file and unzip it.
2. Run the “USB-C Digital Audio Adapter FW updater.exe” .
3. Please make sure the status shows ” USB Audio Connected” and the Start button is in Black.
4. If the status shows “No USB Audio” ,please make sure the earphone connects to USB-C Digital Audio Adapter correctly.

Step 3




Figure 1





Figure 2

1. Click “Start” to update firmware (Figure 1).
2. If there is a warning window showing (Figure 2), this means that the Firmware already update to the latest version.
3. Important! Do not remove the USB-C Digital Audio Adapter from computer or power-off the computer during the update process.

Step 4



Once you see the ” Pass” icon, the Firmware update is complete.



Thank You.

product development